




BD 111 Interpretation Guide




Unexposed



No fault



Large fault



Small fault